

ACTIV-8[®] and ACTIV-8[®] HGL


Drier Accelerator and Stabilizer

Usage Statement

Before using, read, understand and comply with the information and precautions in all applicable Safety Data Sheets, labels and other product literature. The information presented herein, while not guaranteed, was prepared by technical personnel and, to the best of our knowledge and belief, is true and accurate as of the date hereof. No warranty, representation or guarantee, express or implied, is made regarding accuracy, performance, stability, reliability or use. This information is not intended to be all-inclusive, because the manner and conditions of use, handling, storage and other factors may involve other or additional safety or performance considerations. The user is responsible for determining the suitability of any material for a specific purpose and for adopting such safety precautions as may be required. Vanderbilt Minerals, LLC does not warrant the results to be obtained in using any material, and disclaims all liability with respect to the use, handling or further processing of any such material. No suggestion for use is intended as, and nothing herein shall be construed as, a recommendation to infringe any existing patent, trademark or copyright or to violate any federal, state or local law or regulation.

What is **ACTIV-8**®?

- **ACTIV-8 Drier Accelerator and Stabilizer** is a solution of 1,10-phenanthroline in *n*-butanol or hexylene glycol
- **ACTIV-8** is *NOT* a drier
- 1,10-phenanthroline is a **chelating agent**
- **ACTIV-8** works with **cobalt and manganese** driers to stabilize and accelerate the drying time



Typical Properties of **ACTIV-8**[®]

ACTIV-8 Drier Accelerator

Active Ingredient	1,10-phenanthroline (38 %)
Solvents	<i>n</i> -Butanol (52 %) 2-ethylhexoic acid (10 %)
Density	0.95 g/mL
VOC	492 g/L (4.1 lbs/gal)

- **ACTIV-8** accelerates and stabilizes the drying rates of solvent-borne and water-borne coatings that cure by oxidative polymerization

Typical Properties of **ACTIV-8[®] HGL**

ACTIV-8 HGL Drier Accelerator

Active Ingredient	1,10-phenanthroline (38 %)
Solvent	Hexylene glycol (62 %)
Density	1.03 g/mL
VOC	640 g/L (5.3 lbs/gal)

- **ACTIV-8 HGL** is a water miscible drier-accelerator
- The addition of **ACTIV-8 HGL** to the waterborne coating will inhibit the loss of dry

Alkyd Drying and Metallic Driers

- Alkyd coatings form a film and dry by an oxidative process
- Oxygen from the air cross-links the resin
- The oxygen up-take process is catalyzed by the presence of certain transition metals
- Cobalt (top drier) and manganese (through drier) are the most active metallic driers
- Additional metallic driers include zirconium, calcium, zinc, iron, and rare earths

Metallic Driers and **ACTIV-8**[®]

- **ACTIV-8** Drier Accelerator chelates with cobalt and manganese, also with zinc and iron
- By the chelation, the most favorable valence state of the metal is maintained
- Beware of *PINK AND ZINC*
 - Iron plus **ACTIV-8** creates a strong pinkish/red colored complex
 - Zinc plus **ACTIV-8** forms an insoluble compound that does not aid in drying

Why use **ACTIV-8**[®] ?

- For the most consistent drying, a blend of driers and **ACTIV-8** Drier Accelerator is recommended
- **ACTIV-8** and cobalt is the most powerful drying combination
- In water-reducible alkyd coatings that use cobalt as the drier, **ACTIV-8 HGL** will prevent loss of dry

How much ACTIV-8[®] do I need?

- The general rule of thumb is:
 - For **solvent-borne alkyds** use **10 parts** (as supplied) of **ACTIV-8** Drier Accelerator per 1 part of cobalt or manganese metal.
 - For **water-reducible alkyds** use **5 parts** (as supplied) of **ACTIV-8 HGL** per 1 part of cobalt metal.
- There are three steps to determining the amount of **ACTIV-8** to use.

Step 1: Determine the amount of resin solids in the coating

- Determine the amount of resin solids in the coating
- Example:
 - 195 kg of a 90% non-volatile solids alkyd resin solution contains:

$$195 \text{ kg} \times 0.90 = 175 \text{ kg of resin solids}$$

Step 2: Determine the amount of metallic drier to use

- Driers are supplied as solutions of metallic salts of long chain organic acids in various solvents
- Their concentrations are expressed as % metal
- Recommended amounts of driers for air dry coatings are (based on resin solids):
 - Cobalt 0.02—0.05%
 - Manganese 0.02—0.06%

Step 2: Determine the amount of metallic drier to use

- Example:

- For the 175 kg of resin solids in Step 1, determine the amount of 12% cobalt solution that is equivalent to 0.05%

$$175 \text{ kg of resin solids} \times 0.0005 =$$

0.0875 kg of cobalt

$$0.0875 \text{ kg} / 0.12 = 0.729 \text{ kg of 12 \% cobalt solution}$$

Step 3: Determine the amount of **ACTIV-8**[®] Drier Accelerator to use.

- Determine the amount of **ACTIV-8** Drier Accelerator to use
- **Example:**
 - The 0.729 kg of cobalt solution contains 0.0875 kg of cobalt metal.

$$0.0875 \text{ kg} \times 10 = 0.875 \text{ kg of } \mathbf{ACTIV-8}$$

Examples of effectiveness of **ACTIV-8**[®] Drier Accelerator

- Paint: **ACTIV-8 HGL** with cobalt drier in a water-reducible alkyd
- Goal: Improved loss of dry prevention

Formulations

Control	0.15 % Co
Improved Formula	0.15 % Co 0.75 % ACTIV-8 HGL

Drying Test Results

Gardiner Circular Dry Time Recorder - Hours

	Control (0.15 % Co)		Improved Formula (0.15 % Co/0.75 % ACTIV-8 HGL)	
Day 1	Set to touch	1	Set to touch	1
	Tack free	10	Tack free	3
	Hard dry	18	Hard dry	5
Day 60	Set to touch	1	Set to touch	2
	Tack free	14	Tack free	4
	Hard dry	>24	Hard dry	7

- Use of **ACTIV-8 HGL** decreased loss of dry and improved dry times

Examples of effectiveness of **ACTIV-8**[®] Drier Accelerator

- Coating: high gloss black solvent-borne alkyd coating
- Goal: improve drying rate

Formulations

Control

0.05 % Co
0.33 % Zr
0.17 % MEKO

Improved Formula

0.05 % Co
0.33 % Zr
0.17 % MEKO
0.5 % **ACTIV-8**

Drying test results

Gardiner Circular Dry Time Recorder - Hours

	Control (0.05% Co/0.33% Zr/ 0.17% MEKO)		Improved Formula (0.05% Co/0.33% Zr/ 0.17% MEKO/0.5 % ACTIV-8)	
Day 1	Set to touch	3	Set to touch	2
	Surface Dry	17	Surface Dry	4
	Through Dry	27	Through Dry	11
	Hard Dry	>48	Hard dry	22

- Use of **ACTIV-8** significantly improved dry times

Summary

- **ACTIV-8**[®] is *NOT* a drier
- **ACTIV-8** is a drier accelerator
- Use **ACTIV-8** with cobalt or manganese
- For solvent-borne alkyds use 10 parts **ACTIV-8** per 1 part drier metal
- For water-reducible alkyds use 5 parts **ACTIV-8 HGL** per 1 part drier metal

More **ACTIV-8**[®] Resources

- Vanderbilt Minerals, LLC Website
 - www.vanderbiltminerals.com/paint
- Contact Vanderbilt Minerals directly:
 - (800) 562-2476
 - mineralsales@vanderbiltminerals.com

ACTIV-8[®] is a registered trademark of R.T. Vanderbilt Holding Company, Inc. or its respective wholly owned subsidiaries.

More **ACTIV-8**[®] Resources

Visit R.T. Vanderbilt Holding Company, Inc. | Customer Portal

Vanderbilt Minerals, LLC
A Wholly Owned Subsidiary of R.T. Vanderbilt Holding Company, Inc.


Home About **Markets** Contact Technical Inquiry

Search Sales Spec/MSD

Life Sciences	Refractory and Ceramics
Animal Care	Refractories
Personal Care	Ceramics
Pharmaceutical	Industrial and Household
Agri-Science	Paint and Coatings


Industrial & Household

VEEGUM[®] Magnesium Aluminum Silicate and **VAN GEL**[®] Magnesium Aluminum Silicate are naturally occurring smectite clays used to stabilize suspension and emulsion concentrates and to control the rheology of a wide range of products including Industrial & Household applications.




Discover the new VEEGUM[®] CH Magnesium Aluminum Silicate!
Natural Smectite clay for personal care.

[Learn More >](#)




VANZAN[®] Xanthan Gum
It increases viscosity, helps to stabilize emulsions, and prevents the settling of solids in a wide variety of applications. Check out our brochure for more information.

[Learn more >](#)



Special Purpose Paints and Coatings
Read on to find our range of mineral fillers, thixotropes, and chemical additives for solvent-borne and water-borne industrial maintenance and special purpose coatings.

[Read Further >](#)



PYRAX[®] RG Pyrophyllite
PYRAX RG is pyrophyllite providing excellent dimensional stability. **PYRAX RG** is used to make refractories with superior hot load... [read more](#)

[Learn More >](#)

Registered and pending trademarks appearing printed in bold in these materials are those of Vanderbilt Minerals, LLC. For a complete listing, please visit [Trademark Listing](#).

More **ACTIV-8**[®] Resources

Visit R.T. Vanderbilt Holding Company, Inc. | Customer Portal

Vanderbilt Minerals, LLC
A Wholly Owned Subsidiary of R.T. Vanderbilt Holding Company, Inc.

Home About Markets Contact Technical Inquiry

Search Sales Spec/MSD

Paint & Coatings

Paint & Coatings

Categories [Back](#)

Products

- Mineral Products
 - VANSIL[®] Wollastonite
 - PYRAX[®] Pyrophyllite and VEECOTE[®] Pyrophyllite
 - BILT-PLATES[®] Filler, DIXIE CLAY[®] Filler, McNAMEE[®] Filler, PEERLESS[®] Clay
- Chemical Products
 - ACTIV-8[®] Drier, Stabilizer and Accelerator**
 - DARVAN[®] Dispersing Agent
 - VANZAN[®] Xanthan Gum
 - VANCIDE[®] MZ-98 Industrial Preservative

Literature

- Minerals Literature
- Chemicals Literature

Paint and Coatings Videos

Formularies


Formulas

- Architectural Exterior
- Architectural Interior
- Coatings, Industrial Maintenance
- Coatings, Water-borne
- Industrial Special Purpose

Related Menu

MSDS & Sales Specification

Paint & Coatings of **Vanderbilt Minerals, LLC** offers mineral fillers, thixotropes and chemical additives for Solvent-Borne and Water-Borne Interior and Exterior Architectural Paints and Coatings. Primers and top coats can be formulated with our products. Refer to the Architectural Formularies.



VEECOTE[®] Pyrophyllite

Paint & Coatings of **Vanderbilt Minerals, LLC** offers mineral fillers, thixotropes and chemical additives for Solvent-Borne and Water-Borne... [read more](#)

[Learn More](#)

Registered and pending trademarks appearing on this listing, please visit [Trademark Listing](#). Prospector is a registered trademark of R.T. Vanderbilt Holding Company, Inc.

- Product Descriptions
- Sales specifications
- MSDS

Architectural Paints

Vanderbilt Minerals, LLC has functional extender offerings which include **VANSIL[®]** Wollastonite, **BILT-PLATES[®]** 156 Clay, **PYRAX[®]** Pyrophyllite,... [read more](#)

[Learn More](#)

Architectural Floor Finishes

Improve dry time of solvent-borne alkyd varnishes with **ACTIV-8[®]** Drier, Stabilizer and Accelerator prevents loss of dry of water-borne uralkyd varnishes with **ACTIV-8 HGL**.

- Technical data sheets
- A "How-to" guide for the use of **ACTIV-8**
- Examples of **ACTIV-8** effectiveness